

Determination of Dielectric Constant of different materials

Gayatri P

NISER, Bhubaneswar

2nd year, Integrated M.Sc. Physics

Roll No.: 2211185

(Dated: September 29, 2023)

I. THEORY

The dielectric constant, also known as the relative permittivity, plays a vital role in understanding how a material responds to an applied electric field. This property is crucial in the design and optimisation of electronic devices, capacitors, and insulating materials, making it an essential parameter in modern technology.

Electrostatic processes in vacuum can be described by Maxwell's equations as,

$$\oiint \mathbf{E} \cdot d\mathbf{A} = \frac{Q}{\epsilon_o} \quad (1)$$

$$\oint \mathbf{E} \cdot d\mathbf{r} = 0 \quad (2)$$

where \mathbf{E} is the electric field intensity, Q is the charge enclosed by surface A and ϵ_o is the permittivity of free space. For a capacitor with two parallel plates of surface area A , if a potential difference U_c is applied, an electric field \mathbf{E} is formed between them, given by,

$$U_c = \int_1^2 \mathbf{E} \cdot d\mathbf{r} \quad (3)$$




FIG. 1: Electric field lines between the capacitor plates

Due to this electric field, an equal amount of positive and negative charge is formed on both of the capacitor plates respectively. Assuming field lines between the

plates to be perpendicular to the surface, using Eqn. (1) and (3),

$$\frac{Q}{\epsilon_o} = \frac{U_c}{d} A \quad (4)$$

for small distances d . Since the charge on a capacitor is directly proportional to the potential difference between the plates, one can write,

$$Q = CU_c = \epsilon_o \frac{U_c A}{d} \quad (5)$$

where C — the constant of proportionality — is the capacitance of the capacitor. From Eq (5), we can infer that,

$$C = \frac{\epsilon_o A}{d} \quad (6)$$

which shows that the capacitance is inversely proportional to the distance between the plates and directly proportional to the area of the plates. These are the intrinsic properties of a particular capacitor.

Dielectric between the Capacitor Plates

Eq. (6) is derived with the assumption that there is vacuum between the plates, which has to be modified with the introduction of a dielectric (insulating material) between the plates.

Dielectrics have no free moving charge carriers, as metals have, but they do have positive nuclei and negative electrons, which can arrange itself along the lines of an applied electric field \mathbf{E}_0 . Formerly non-polar molecules thus get polarized and behave as locally stationary dipoles. The effects of the single dipoles cancel each other macroscopically inside the dielectric, but not on the surface. Hence the surfaces will possess a stationary charge, called a free charge. The free charges in turn weaken the effective electric field \mathbf{E} as given below,

$$\mathbf{E} = \frac{\mathbf{E}_0}{\epsilon_r} \quad (7)$$

where ϵ_r is the relative permittivity (or dielectric constant) of the medium.




FIG. 2: Electric field lines between capacitor plates with a dielectric in between. Notice the dipoles aligned in the direction of the external electric field.

The induced electric field \mathbf{E}_P due to these charges will be in opposite direction to the applied electric field. If \mathbf{P} is the polarization vector of the medium,

$$\begin{aligned} \mathbf{E}_P &= \mathbf{E}_0 - \mathbf{E} = \mathbf{E}_0 \left(1 - \frac{1}{\epsilon_r}\right) \\ &= \frac{\mathbf{P}}{\epsilon_o} \end{aligned} \quad (8)$$

The electric displacement vector for an isotropic medium is defined as,

$$\mathbf{D} = \epsilon \mathbf{E} = \epsilon_o \epsilon_r \mathbf{E} = \epsilon_o \mathbf{E} + \mathbf{P} \quad (9)$$

where ϵ is the electrical permittivity of the dielectric medium. When a dielectric is inserted between the capacitor plates, according to Eq. (3), voltage U_c between the plates is reduced by the dielectric constant, ϵ_r , as compared to voltage in vacuum. Since the charge stored is constant, the capacitance will increase by a factor of ϵ_r .

$$C_{\text{dielectric}} = \epsilon_r \epsilon_o \frac{A}{d} \quad (10)$$

$$\Rightarrow Q = \epsilon_r \epsilon_o \frac{A U_c}{d} \quad (11)$$

Thus if one knows all the parameters, they can determine the dielectric constant of the medium by rearranging the above equation,

$$\epsilon_r = \frac{d}{\epsilon_o A} \cdot \frac{Q}{U_c} \quad (12)$$

II. EXPERIMENTAL SETUP

The schematic for the setup is given in Fig (3). Initially the plate capacitors are charged using a high voltage supply. Then the charge is transferred to a known capacitor

C_{ref} (220nF). The voltage across C_{ref} , V_o is measured by the voltmeter. From this, the total stored on the capacitor is calculated by $Q = V_o C_{\text{ref}}$. Subsequently, using Eq. (12), we can find the value of ϵ_r for different media.




FIG. 3: Experimental setup schematic

Apparatus

1. Set of parallel plate capacitors (Diameter = 26 cm)
2. High voltage power supply (0-10 kV)
3. A 10 MΩ resistor
4. Reference capacitor (220nF)
5. Universal measuring amplifier
6. Voltmeter
7. Dielectric materials (Plastic and glass plates)
8. Connecting cables, adapters, T-connectors

III. OBSERVATIONS AND CALCULATIONS

Observational Data

1. For Air

Measurement of charge Q for different supply voltage U_c

Measurement of charge Q for different distances d

2. For Styrofoam

3. For Wood

Calculations

4. For Air

Measurement of charge Q for different supply voltage U_c From the plot, we can see that

Measurement of charge Q for different distances d

5. *For Styrofoam*

6. *For Wood*
